

**SAN REMO STOVES**  
**4,6,8,12 and 16kW**

**FREESTANDING**  
**WOOD BURNING**  
**STOVES**

**Installation and Operating**  
**Instructions**


**Please hand these instructions to the stove user when the installation is complete. Leave the system ready for operation and instruct the user in the correct use of the appliance and operation of controls.**

**Installation – Must be installed by a qualified plumber or suitably qualified fitter**

## **Assembly Instructions**

**PLEASE READ THESE INSTRUCTIONS CAREFULLY**


**It is important that your stove is correctly installed, as San Remo Stoves cannot accept responsibility for any fault arising through incorrect installation.**



**1. Your San Remo Stove comes packed in a plywood crate. Carefully remove the steel straps and lift off the upper crate.**

**2. Remove the plastic bag and upon opening the door remove all the contents**

**3. Remove the stove from the pallet and carefully tip it onto it's back**



**4. Sort out the legs and fixings**

**5. Ensure the tapped holes, on the base, are free from obstruction. Use a sharp screwdriver to remove any fire cement.**

**6. Fit the Flue Collar using the 4-M6 set screws and washers supplied. Screw The M6 nuts on the M6 screws all the way to the end. Then put the washer over the screw/nut assembly and secure the collar to the lid/back as desired.**

**The flue collar is shown below fixed to the top of the stove. If a back flue outlet is required then remove the blanking plate from the back and fit the collar in its place. Refit the blanking plate to the top of the stove.**



**7. To fit the Baffle:**


**Insert the baffle, upside down, as shown, ensuring you are holding the shorter of the two sides. Turn the baffle as you fit it, so that the edge that you are holding is placed on the ledge at the rear of the stove. The other edge rests on a lip behind two holding bars at the back of the Air Wash Chamber.**



## List of Components

### Description of Parts

<b>Door Handle</b>	<b>1</b>
<b>Airwash Control Handle</b>	<b>1</b>
<b>Primary Air Caps</b>	<b>2</b>
<b>Riddling Handle</b>	<b>1</b>
<b>Ash Pan</b>	<b>1</b>
<b>Ash Pan Tool</b>	<b>1</b>
<b>Coal Guard</b>	<b>1</b>
<b>Baffle Plate</b>	<b>1</b>
<b>Legs</b>	<b>4</b>
<b>Leg Height Screws M17</b>	<b>4</b>
<b>Leg Screws M14</b>	<b>8</b>
<b>Leg Washers</b>	<b>8</b>
<b>Flue Collar</b>	<b>1</b>
<b>Flue Collar Screws M10</b>	<b>4</b>
<b>Flue Collar Nuts M10</b>	<b>4</b>
<b>Flue Collar Washers</b>	<b>4</b>



## **Installation Instructions**

### **READ THESE INSTRUCTIONS CAREFULLY BEFORE INSTALLATION**

These instructions cover the basic principles to ensure satisfactory installation of the stove, although detail may need slight modification to suit particular local site conditions. In all cases the installation must comply with National and European Building Regulations, Local Authority Byelaws and other specifications or regulations as they affect the installation of the stove.

### **Health and Safety Precautions**

#### **Handling**

Adequate facilities must be available for unloading and site handling.

#### **Fire Cement**

Some types of fire cement are caustic and should not be allowed to come into contact with the skin. In case of contact, wash immediately with plenty of water.

#### **Asbestos**

This stove contains no asbestos. If there is a possibility of disturbing any asbestos in the course of installation then please seek specialist guidance and use appropriate protective equipment.

#### **Metal Parts**

When installing or servicing this stove, care should be taken to avoid the possibility of personal injury.

#### **Please note:**

Any white deposits on the stove joints are caused by humidity reacting with the joint sealant. These deposits may be brushed off and, if necessary, blackened with a proprietary stove polish.

### **Important Warning**

This stove must **not** be installed into a chimney that serves any other heating appliance.

No purpose provided ventilation is required for stoves rated under 5KW. For each KW above 5KW, 550 sq mm of fixed ventilation is required – i.e. a stove rated at 8KW would require 3 x 550 sq mm = 1650 sq mm of fixed ventilation. If more than one appliance is installed in the same room, the ventilation requirements for each appliance must be added together.

There must not be an extractor fan fitted in the same room as the stove as this can cause the stove to emit fumes into the room.

## **Installation**

### **Chimney**

The chimney height and the position of the chimney terminal should conform to Building Regulations. Check that the chimney is in good condition, dry, free from cracks and obstructions.

The diameter of the flue should not be less than 125mm and not more than 200mm. If any of these requirements are not met, the chimney should be lined by a suitable method. The chimney must be swept before connection to the stove.

Where the chimney is believed to have previously served an open fire installation, it is possible that the higher flue gas temperature from the stove may loosen deposits that were previously firmly adhered, with the consequent risk of flue blockage. It is therefore recommended that the chimney be swept a second time within a month of regular use after installation. If you have any doubts about the suitability of your chimney, consult your local dealer/stockist.

If there is no existing chimney then either a prefabricated block chimney or a twin-walled insulated stainless steel flue to BS 4543 can be used. These chimneys must be fitted in accordance with the manufacturer's instructions and Building Regulations.

### **Flue Draught**

A flue draught of minimum 1.2mm to a maximum 2.5mm water gauge is required for satisfactory appliance performance. The flue draught should be checked under fire at high output and, if it exceeds the recommended maximum, a draught stabiliser must be fitted so that the rate of burning can be controlled and to prevent overfiring.

### **Connection to the Chimney**

An existing fireplace opening can be bricked up or sealed with a register plate. A short length of flue pipe of a minimum 125mm internal diameter may then be used to connect the stove to the chimney. This flue pipe should conform to Building Regulations. Ensure that the pipe end is no closer than 76mm to the side or rear chimney walls.

Ideally, the old fireplace should be filled in so that there is a smooth streamlined entry into the flueway. The length of any horizontal run of flue pipe must not exceed 125mm.

It is essential that all connections between the stove and chimney-flue are sealed and made airtight. This appliance is not suitable for installation in a shared flue system.

Both the chimney and flue pipe must be accessible for cleaning and if ANY parts of the chimney cannot be reached through the stove (with baffle removed), a soot door must be fitted in a suitable position to enable this to be done.

### **Material Clearances**

The stove can be recessed in a suitable sized fireplace but a permanent free air gap of at least 150mm must be left around the sides and top and at least 50mm at the back of the stove to obtain maximum heat output and for access to the rear of the stove.

All non-combustible walls closer than 400mm to the stove should be at least 75mm thick. In all instances the back wall of the fireplace recess and the hearth should be made of non-combustible material. Allow an apron of at least 300mm at the front of the stove and 150mm on either side. The hearth on which the stove is to be placed should not be less than 125mm thick and should be in accordance with the current building regulations.

Care should be taken to level the stove using the adjusting screws in the feet.

The appliance shall be installed on a floor with adequate load-bearing capacity. If the existing construction does not meet this prerequisite, suitable measures (e.g. load disturbing plate) should be taken to achieve it.

Safety Distances from Combustible Surfaces:

	Side	Rear
San Remo 4	500mm	700mm
San Remo 6	400mm	400mm
San Remo 8	500mm	500mm
San Remo 12	700mm	1000mm
San Remo 16	600mm	600mm

### Commissioning and Handover

Upon completion of the installation, allow a suitable period of time for any fire cement and mortar to dry out. A small fire may then be lit and checked to ensure the smoke and fumes are taken from the stove up the chimney and emitted safely to atmosphere. Do not run the stove at full output for at least 3 – 4 days.

On completion of the installation and commissioning, ensure that the operating instructions and operating tools for the stove are left with the customer. Ensure to advise the customer on the correct use of the appliance with the fuels likely to be used on the stove and warn them to use only the recommended fuels for the stove.

Advise the user on what to do should smoke or fumes be emitted from the stove. The user should use a suitable fireguard in the presence of children, aged and/or infirm persons.

	San Remo 4	San Remo 6	San Remo 8	San Remo 12	San Remo 16
Appliance weight:	75kg	100kg	135kg	180kg	211kg
Flue gas mass flow: g/s	3.5	3.9	5.0	7.4	9.8
*Flue Temp: Deg C	247	296	293	335	345
*under nominal heat output					

## Operating Instructions

This appliance is **not** suitable for use in a shaped flue.

This appliance should **not** be operated with the doors open.

### Aerosol Sprays

Do not use an aerosol spray on or near the stove when it is alight.

### **Air Controls**

This stove has been designed to burn clean and efficient. If used correctly this stove will burn far more efficiently than normal with the obvious notable features of CLEAN GLASS. Never clean glass when stove is hot. Always use stove glass cleaner which is available from your stove retailer.

However, for this product to work properly it must be used correctly. It is essential that the stove has an adequate air supply for combustion and ventilation.

The primary and secondary air inlets must be kept clear from obstruction.

### **Note:**

**The secondary air control is open when pushed to the right.**

**Warning!** This appliance will be **hot** when in operation and due care should be taken when operating the controls.

### **Air Controls**

#### **Primary Air**

Primary air is controlled via the two rotary air controls on the bottom of the door. This provides a conventional air draught to the bed of the fire. The primary air intakes can be adjusted to give the best possible results when burning different fuels.

#### **Secondary Air**

The cast iron stove is fitted with a sophisticated “air wash” system. This secondary air supply to the stove is controlled through a slider assembly located at the top of the stove.

### **Multifuel Grate**

Your San Remo Stove is fitted with a rotary style grate, which is operated from the front of the stove via a riddle rod. Use the “Hook” end of tool to operate the riddling system. This rotary grate is located in the centre of a cast iron flat bed with suitable air slots that assist the burning of most fuels. It is important to use the rotary grate to de-ash regularly, to ensure that the primary airflow is not impeded, as a build-up of ash can damage the cast iron bed.

### **Ashpan**

It is essential that you empty the ashpan regularly. Use the “T” end of tool to lift the ashpan out of the stove.

### **Notes on Wood burning**

With a full load of wood, the stove will need to be refuelled approximately every 1.5 hours. Wood can be stacked higher in the stove than solid mineral fuel but care must be taken that logs do not touch the baffle.



Wood burns most efficiently with the primary air controls closed and the secondary control partially open. Moving the secondary control will control the burn rate of the stove.

Note – primary and secondary air is needed to light the stove, see section entitled ‘Lighting the Stove’.

Wood burns best on a bed of ash and it is therefore only necessary to remove surplus ash from the stove occasionally.

Burn only dry, well-seasoned wood, which should have been cut, split and stacked for at least 12 months, with free air movement around the sides of the stack to enable it to dry out. Burning wet or unseasoned wood will create tar deposits in the stove and chimney and will not produce a satisfactory heat output. Do not use liquid fuels in this appliance.

### **Size of Fuel**

#### Log Size

San Remo 4kW	up to 260mm
San Remo 6kW	up to 300mm
San Remo 8kW	up to 340mm
San Remo 12kW	up to 380mm
San Remo 16kW	up to 430mm

### **Lighting the Stove**

We recommend that you have two or three small fires before you operate your stove to its maximum heat output. This is to allow the paint to cure steadily and to give a long service life of the paint finish. During this curing process you may notice an unpleasant smell. It is non-toxic, but for your comfort we would suggest that during this period you leave all doors and windows open.

First, load the fire with starting fuel, i.e. paper, dry sticks and/or firelighters in the mode chosen, either wood or solid mineral fuel.

Light the fire at the base leaving all air controls open. Allow the fuel to reach a steady glow and build the fire up gradually. Once you have a good fire established across the grate bed, further fuel can be added as required.

### **Shutting Down**

In order to shut down the stove, close the primary air controls, then close the secondary air slider by moving the handle all the way to the left. If the controls are left in this position, the fire will be starved of air and will go out. If you want to revive the fire it is recommended that the primary air controls are open first, then open the secondary air slider.

**Warning!** - The stove will remain **hot** for a considerable time after the fire has been extinguished.

## Notes:

**Warning!** - Petroleum coke fuels or household waste must not be burnt on this appliance. Should any difficulties arise over fuel quality or suitability, consult your local approved coal merchant.

## **Safety Notes for your guidance**

***FIRES CAN BE DANGEROUS*** – Always use a fireguard in the presence of children, the elderly or the infirm.

**DO NOT OVERFIRE** – it is possible to fire the stove beyond its design capacity, this could damage the stove, so watch for signs of overfiring – if any part of the stove starts to glow red, the fire is in an overfire situation and the controls should be adjusted accordingly. Never leave the stove unattended for long periods without first adjusting the controls to a safe setting – careful air supply control should be exercised at all times.

Any unauthorised modifications of this appliance will render the guarantee null and void and could be potentially dangerous. Replacement parts should only be sourced from San Remo approved dealers

### **WARNING – FUME EMISSION**

Properly installed and operated, this appliance will not emit fumes. Occasional fumes from de-ashing and refuelling may occur. Persistent fume emission must not be tolerated.

If fume emission does persist, then the following immediate action should be taken: -

1. Open doors and windows to ventilate room
2. Let the fire out, or eject and safely dispose of fuel from the appliance.
3. Check for flue chimney blockage and clean if required.
4. Do not attempt to re-light the fire until the cause has been identified and corrected.

If necessary, seek professional advice.

**Important!** – Do not fit an extractor fan in the same room as this appliance.

### **IN THE EVENT OF A CHIMNEY FIRE**

- Raise the alarm to let others in the house know.
- Call the Fire Brigade
- Reduce the appliance-burning rate by closing all air controls.
- Move furniture and rugs away from the fireplace and remove any nearby ornaments.
- Place a fireguard or spark guard in front of the stove.
- Feel the chimneybreast for sign of excessive heat.

If the wall is becoming hot, move the furniture away. Ensure that the Fire Brigade can gain access to your roof space in order to check this area for signs of fire spread

## **Frequently Asked Questions**

### ***1 Do stoves require a chimney?***

All of our multi fuel and wood burning stoves require a suitable chimney or professionally installed flue system.

### ***2 How do I clean the chimney?***

You will require a chimney sweep to clean the chimney. It is best to provide a dedicated chimney cleaning access door when installing the flue of the stove.

### ***3 Who should install my stove?***

San Remo want you to enjoy the maximum performance from your Stove products. To ensure this, it is essential that they are installed correctly.

We strongly recommend that your San Remo Stove products are installed by a qualified plumber or suitably qualified person.

### ***4 How do I regulate the heat output?***

Each stove will have spin valves, which will allow you to easily regulate the heat output.

### ***5 What warranty policy do I get?***

San Remo Stoves will replace, free of charge, any working part that fails (under normal operating conditions) within 12 months of purchase. Consumables such as glass or stove rope are not guaranteed.

***A call out charge will apply if our engineer attends any stove problem that is not related to product failure.***

### ***6 Where can I get spare parts?***

Your local San Remo Stove retailer will be pleased to supply spare parts and to provide any other information you require.

### ***7 Can the doors be left open while burning?***

For safety and heat efficiency the doors should remain closed at all times.

### ***8 Why is the stove smoking when lit?***

A smoking stove can be caused by a flue with back draught problems. A qualified fitter should complete a smoke test prior to fitting the stove to ascertain the integrity of the flue.

### ***9 Why should I "Run in" my stove?***

To begin, light a series of small fires over a period of a few days to allow the paint finish to cure. The stove is finished with a heat resistant paint and this can be cleaned with a soft brush. Do not clean whilst the stove is hot; wait until it has cooled down. The finish can be renovated with proprietary stove paint

If the stove is not "run in" correctly, this may cause the paint to discolour and flake.

### ***10 What is Over Firing?***

Your stove should never be used in a manner to cause over firing. Over firing can be caused by over loading the stove with fuel, and with primary controls open. If any part of stove glows "red" your stove is over firing and your draught control should be adjusted to restrict airflow to stove. Over firing can cause permanent damage to the appliance which is not covered by warranty.

**San Remo Stoves**, 30-60 Hawthorn Road, Western Industrial Estate, Naas Road, Dublin 12.  
**T:** 01 408 9192      **F:** 01 408 9193

HD01 18/12/11